



USE AND CARE GUIDE

Model # RFF15NC


1-1/2" Silent Sump Pump Clear Check Valve




Tools Required:



Safety Goggles



Hacksaw or PVC Cutter



Tape Measure



Flathead Screwdriver

SAFETY INFORMATION:




WARNING

ALWAYS DISCONNECT POWER TO YOUR PUMP AND RELEASE PRESSURE BEFORE SERVICING.

INSTALLATION:

Note: For use in residential sump pump applications only.
MAXIMUM 12 PSI.

1. Unplug your pump.
2. Disconnect the pump's discharge pipe from below your existing check valve.
3. Drain the discharge pipe above the check valve into your basin or a bucket and remove the old check valve.
4. Loosen all four hose clamps on your new check valve.
5. Ensure the spacing between the two discharge pipes is $5 \frac{1}{8}$ ". Cut the discharge pipe as necessary.
6. Install your new check valve with the flow arrow pointing away from the pump by inserting the two pipe ends into the flexible rubber adapters.
7. Position the check valve assembly as shown and tighten all four hose clamps. Do not exceed 20 in-lbs. Do not over-tighten.
8. Plug in your pump and fill basin with water to cycle your system a few times checking for leaks. Retighten hose clamps if necessary. Do not over-tighten.



Limited Two-Year Warranty

WHAT THIS WARRANTY COVERS:

When used and maintained in normal use and in accordance with the Owner's Manual, your RAYBEND® product is warranted against original defects in material and workmanship for a full 2 years from the date of purchase (the "Warranty Period"). During the Warranty Period, RAYBEND® will repair or replace at no cost to you, to correct any such defect in products found upon examination by RAYBEND® to be defective in materials or workmanship.

WHAT THIS WARRANTY DOES NOT COVER:

Use of the product in a non-residential application, improper installation and/or maintenance of the product, damage due to misuse, acts of God, nature vandalism or other acts beyond control of RAYBEND®, owner's acts or omissions, use outside the country in which the product was initially purchased and resales of the product by the original owner. This warranty does not cover pick up, delivery, transportation or house calls. However, if you mail your product to a RAYBEND® Sales and Service Center for warranty service, cost of shipping will be paid one way. This warranty does not apply to products purchased outside of the United States, including its territories and possessions, outside of U.S. Military Exchange and outside of Canada. This warranty does not cover products purchased from a party that is not an authorized retailer, dealer or distributor of RAYBEND® products.

OTHER IMPORTANT TERMS:

This warranty is not transferable and may not be assigned. This Warranty shall be governed and construed under laws of the state of Michigan. The Warranty Period will not be extended by any replacement or repair performed under this Warranty. THIS WARRANTY IS THE EXCLUSIVE WARRANTY AND REMEDY PROVIDED BY RAYBEND®. ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING WARRANTIES OR MERCHANTABILITY OR FITNESS FOR PARTICULAR PURPOSE, ARE DISCLAIMED. IN NO EVENT WILL RAYBEND® BE LIABLE FOR ANY SPECIAL, INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES OF ANY KIND OR NATURE TO OWNER OR ANY PARTY CLAIMING THROUGH OWNER WHETHER BASED IN CONTRACT, NEGLIGENCE, TORT, OR STRICT PRODUCTS LIABILITY OR ARISING FROM ANY CAUSE WHATSOEVER. Some states do not allow for the exclusion of consequential damages, so the above exclusion may not apply to you. This warranty gives you specific rights. You may also have other that vary from state to state.



2723 Kersten Court • Kalamazoo, Michigan 49048 • 269-254-8497
www.RAYBEND.com